



R0930 Freeny reading chair in maple, with upholstered seat, wood frame and stretchers  
W20 D21 1/2 H37 3/4 SH18 3/4

R0931 Freeny reading chair in maple, with wood saddle seat, wood frame and stretchers  
W20 D21 1/2 H37 3/4 SH18  
(Not Shown)

R0934 Freeny arm chair in maple, with upholstered seat, wood frame and stretchers  
W23 1/2 D21 1/2 H37 3/4 SH18 3/4  
(Not Shown)

R0935 Freeny arm chair in maple, with wood saddle seat, wood frame and stretchers  
W23 1/2 D21 1/2 H37 3/4 SH18  
(Not Shown)